



No strips, glue, grinding or retensioning bolts!

How to install the shur-loc® "E-Z" Stretcher

Tools Required:

- You will need a board or table for mounting, a drill motor and a 1/4" drill bit.

Getting Started



Kit includes: 1 "E-Z" Stretcher, (2) 1/4-20 x 4" bolts, (2) washers, (2) wing nuts.

STEP 1



Position the stretcher on the edge of the table top or board allowing the handle to rotate 180°.

STEP 2



Use the drill motor with the 1/4" bit to drill through the table or board using the bolt holes as a vertical drill jig.

STEP 3



Install the 4" 1/4-20 bolts through the holes that were drilled in the table top or board.

STEP 4



Install the washers and wing nuts under the table top or board and tighten.

STEP 5



The stretcher is now completely assembled and ready to use with the shur-loc® "E-Z" Frame.

For more information or to view our online videos online of how to use your shur-loc® "E-Z" Frame visit us at www.shurloc.com.

ADDITIONAL ACCESSORIES AVAILABLE FROM shur-loc®



shur-loc® Fabric Panels

shur-loc® "E-Z" Fabric Protectors

shur-loc® "E-Z" Retensioning Bars

shur-loc® PMI Split Tape

(360) 805-4140 • www.shurloc.com • fax: (360) 805-4141